



Manufacturer

**TLV** CO., LTD.

Kakogawa, Japan

is approved by LRQA LTD. to ISO 9001/14001



# Instruction Manual

## Thermodyne Steam Trap **P46SR**

Copyright © 2009 by TLV CO., LTD.

All rights reserved

## Contents

Introduction .....	1
Safety Considerations .....	2
Checking the Piping .....	4
Specifications .....	5
Configuration .....	5
Installation .....	6
Maintenance .....	7
Disassembly / Reassembly .....	8
Troubleshooting .....	10
Product Warranty .....	11
Option: With BO2 Blowdown Valve .....	12

## Introduction

Thank you for purchasing the **TLV** Thermodyne Steam Trap.

This product has been thoroughly inspected before being shipped from the factory. When the product is delivered, before doing anything else, check the specifications and external appearance to make sure nothing is out of the ordinary. Also be sure to read this manual carefully before use and follow the instructions to be sure of using the product properly.

The Thermodyne Steam Trap features a bimetal ring for thermostatic air venting, which allows the quick, automatic discharge of large quantities of initial air and cold condensate immediately after operation start-up, thereby greatly reducing start-up time. It also reacts with great sensitivity to the inflow of large quantities of condensate and hot air during operation, preventing air binding.

The modular valve seat unit is quickly and easily installed and replaced, thus greatly reducing the time and labor required for maintenance and repair.

The Thermodyne Steam Trap, with its superior features listed above, in combination with the proven performance record of the bimetal thermostatic air vent, increases heating efficiency and reduces manpower requirements for maintenance and bypass blowdown.

If detailed instructions for special order specifications or options not contained in this manual are required, please contact **TLV** for full details.

This instruction manual is intended for use with the model(s) listed on the front cover. It is necessary not only for installation but for subsequent maintenance, disassembly/reassembly and troubleshooting. Please keep it in a safe place for future reference.

## Safety Considerations

- Read this section carefully before use and be sure to follow the instructions.
- Installation, inspection, maintenance, repairs, disassembly, adjustment, and valve opening/closing should be carried out only by trained maintenance personnel.
- The precautions listed in this manual are designed to ensure safety and prevent equipment damage and personal injury. For situations that may occur as a result of erroneous handling, three different types of cautionary items are used to indicate the degree of urgency and the scale of potential damage and danger: DANGER, WARNING and CAUTION.
- The three types of cautionary items above are very important for safety: be sure to observe all of them as they relate to installation, use, maintenance, and repair. Furthermore, TLV accepts no responsibility for any accidents or damage occurring as a result of failure to observe these precautions.

### Symbols

	<b>Indicates a DANGER, WARNING or CAUTION item.</b>
	Indicates an urgent situation which poses a threat of death or serious injury
	Indicates that there is a potential threat of death or serious injury
	Indicates that there is a possibility of injury or equipment / product damage

	<b>Install properly and DO NOT use this product outside the recommended operating pressure, temperature and other specification ranges.</b> Improper use may result in such hazards as damage to the product or malfunctions that may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.
	<b>Take measures to prevent people from coming into direct contact with product outlets.</b> Failure to do so may result in burns or other injury from the discharge of fluids.
	<b>When disassembling or removing the product, wait until the internal pressure equals atmospheric pressure and the surface of the product has cooled to room temperature.</b> Disassembling or removing the product when it is hot or under pressure may lead to discharge of fluids, causing burns, other injuries or damage.
	<b>Be sure to use only the recommended components when repairing the product, and NEVER attempt to modify the product in any way.</b> Failure to observe these precautions may result in damage to the product and burns or other injury due to malfunction or the discharge of fluids.

Safety considerations continued on next page.

 <b>CAUTION</b>	<b>Do not use excessive force when connecting threaded pipes to the product.</b>
	Over-tightening may cause breakage leading to fluid discharge, which may cause burns or other injury.
	<b>Use only under conditions in which no freeze-up will occur.</b>
	Freezing may damage the product, leading to fluid discharge, which may cause burns or other injury.
	<b>Use only under conditions in which no water hammer will occur.</b>
	The impact of water hammer may damage the product, leading to fluid discharge, which may cause burns or other injury.









## Checking the Piping



Use only under conditions in which no water hammer will occur. The impact of water hammer may damage the product, leading to fluid discharge, which may cause burns or other injury.

Check to make sure that the pipes to be connected to the trap have been installed properly.

1. Is the pipe diameter suitable?
2. Has sufficient space been secured for maintenance?
3. Have isolation valves been installed at the inlet and outlet? If the outlet is subject to back pressure, has a check valve (TLV-CK) been installed?
4. Is the inlet pipe as short as possible, with as few bends as possible, and installed so the liquid will flow naturally down into the trap?
5. Has the piping work been done correctly, as shown in the figures below?

Requirement	Correct	Incorrect
Install catchpot with the proper diameter.		 Diameter is too small.
Make sure the flow of condensate is not obstructed.		 Diameter is too small and inlet protrudes into pipe interior.
To prevent rust and scale from flowing into the trap, the inlet pipe should be connected 25 – 50 mm (1 – 2 in) above the base of the T-pipe.		 Rust and scale flow into the trap with the condensate.
When installing on the blind end, make sure the flow of condensate is not obstructed.		 Condensate collects in the pipe.

## Specifications




Install properly and **DO NOT** use this product outside the recommended operating pressure, temperature and other specification ranges. Improper use may result in such hazards as damage to the product or malfunctions which may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.



Use only under conditions in which no freeze-up will occur. Freezing may damage the product, leading to fluid discharge, which may cause burns or other injury.


Refer to the product nameplate for detailed specifications.



\* Maximum allowable pressure (PMA) and maximum allowable temperature (TMA) are PRESSURE SHELL DESIGN CONDITIONS, **NOT** OPERATING CONDITIONS.

\*\* Valve No. is displayed for products with options. This item is omitted from the nameplate when there are no options.

## Configuration



No.	Name	M*	R*
1	Body		
2	Cover		√
3	Valve Seat Module		√
4	Disc		√
5	Screen Outside/Inside		√
6	Screen Holder Gasket	√	√
7	Screen Holder		
8	Air Vent Ring		√
9	Disc Holder Ring		√
10	Cap		√
11	Outer Module Gasket	√	√
12	Inner Module Gasket	√	√
13	Nameplate		√
14	Flange		

\* Replacement parts are available only in the following kits:

M = Maintenance kit

R = Repair kit

## Installation



Install properly and DO NOT use this product outside the recommended operating pressure, temperature and other specification ranges. Improper use may result in such hazards as damage to the product or malfunctions which may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.



Take measures to prevent people from coming into direct contact with product outlets. Failure to do so may result in burns or other injury from the discharge of fluids.

Installation, inspection, maintenance, repairs, disassembly, adjustment and valve opening/closing should be carried out only by trained maintenance personnel.

Note: For products with socket weld connections, electric weld with a single pass.

As internal parts are not damaged by the welding process if limited to a single pass, there is no need to remove them before welding.

1. Before installing the product, open the inlet valve and blow out the piping to remove any piping scraps, dirt and oil. Close the inlet valve after blowdown.
2. Before installation, be sure to remove all protective seals.
3. Install the product so the arrow on the body is pointing in the direction of flow.
4. The trap may be installed either horizontally or vertically; there are no restrictions on the orientation of installation. (Fix the trap securely in place.)
5. Install a condensate outlet valve and outlet piping.
6. Open the inlet and outlet valves and check to make sure that the product functions properly.

If there is a problem, determine the cause using the “Troubleshooting” section in this manual.

## Maintenance



Take measures to prevent people from coming into direct contact with product outlets. Failure to do so may result in burns or other injury from the discharge of fluids.



Be sure to use only the recommended components when repairing the product, and NEVER attempt to modify the product in any way. Failure to observe these precautions may result in damage to the product or burns or other injury due to malfunction or the discharge of fluids.

## Operational Check

A visual inspection of the following items should be done on a daily basis to determine whether the trap is operating properly or has failed. Periodically (at least biannually) the operation should also be checked by using diagnostic equipment, such as a stethoscope, thermometer, TLV TrapMan or TLV Pocket TrapMan.

If the trap should fail, it may cause damage to piping and equipment, resulting in faulty or low quality products or losses due to steam leakage.

Normal	: Condensate is discharged intermittently together with flash steam, and the sound of flow can be heard.
Blocked (Discharge Impossible)	: No condensate is discharged. The trap is quiet and makes no noise, and the surface temperature of the trap is low.
Blowing	: Live steam continually flows from the outlet and there is a continuous metallic sound.
Steam Leakage	: Live steam is discharged through the trap outlet together with condensate, accompanied by a high-pitched sound.

(When conducting a visual inspection, flash steam is sometimes mistaken for steam leakage. For this reason, the use of a steam trap diagnostic instrument [TLV: TrapMan] in conjunction with the visual inspection is highly recommended.)

## Parts Inspection

When parts have been removed, or during periodic inspections, use the following table to inspect the parts and replace any that are found to be defective.

Procedure
Gaskets: check for warping or scratches
Screen: check for clogging or corrosion
Disc: check for scratches or wear
Air Vent Ring: check for scratches or wear
Disc Holder Ring: check for scratches or wear
Modular Valve Seat Surface: check for scratches or wear
Check for build-up inside the body

## Disassembly / Reassembly



When disassembling or removing the product, wait until the internal pressure equals atmospheric pressure and the surface of the product has cooled to room temperature. Disassembling or removing the product when it is hot or under pressure may lead to discharge of fluids, causing burns, other injuries or damage.

Use the following procedures to remove components. Use the same procedures in reverse to reassemble.


(Installation, inspection, maintenance, repairs, disassembly, adjustment and valve opening/closing should be carried out only by trained maintenance personnel.)

### Removing / Reattaching the Cap

Part	During Disassembly	During Reassembly
Cap	Gently turn the cap to remove	Being careful not to bend it, gently turn the cap to tighten

### Removing / Reattaching the Cover and its Components

Part	During Disassembly	During Reassembly
Cover	Remove with a socket wrench	Consult the table of tightening torques and tighten to the proper torque
Disc	Remove carefully, being careful not to scratch the polished seat surface	Be careful that the seat surface (the lapped side) is facing down (toward the body)
Disc Holder Ring	Remove without bending	Set on the air vent ring; make sure that it does not sit on the valve seat surface
Air Vent Ring	Remove without bending	Reinsert without bending
Module Valve Seat	Remove carefully, being careful not to scratch the polished seat surface	Insert into the body levelly, being careful not to tilt it or to scratch the seat surface (Figure A)
Outer Module Gasket	Remove with a screwdriver, or other suitable tool and clean the gasket housing	Replace with a new gasket if damaged
Inner Module Gasket	Remove with a screwdriver, or other suitable tool and clean the gasket housing	Replace with a new gasket if damaged



### Disassembly / Reassembly of Components Inside the Body

Part	During Disassembly	During Reassembly
Screen Holder	Remove with a socket wrench	Consult the table of tightening torques and tighten to the proper torque
Screen Holder Gasket	—	Replace with new gasket; coat surfaces with anti-seize
Screen	Remove without bending	Reinsert without bending

### Table of Tightening Torques


Part Name	Torque		Distance Across Flats	
	N·m	(lbf·ft)	mm	(in)
Cover	160	(115)	41	(1 <sup>5</sup> / <sub>8</sub> )
Screen Holder	60	(44)	22	(7 <sup>7</sup> / <sub>8</sub> )

NOTE: - Coat all threaded portions with anti-seize.

1 N·m ≈ 10 kg·cm

- If drawings or other special documentation were supplied for the product, any torque given there takes precedence over values shown here.

### Exploded View



## Troubleshooting



When disassembling or removing the product, wait until the internal pressure equals atmospheric pressure and the surface of the product has cooled to room temperature. Disassembling or removing the product when it is hot or under pressure may lead to discharge of fluids, causing burns, other injuries or damage.

When the product fails to operate properly, use the following table to locate and remedy the cause.

Problem	Cause	Remedy
No condensate is discharged or discharge is poor (blocked)	Module valve seat, screen or piping are clogged with rust or scale	Clean parts
	Disc is stuck to the module valve seat	Clean parts
	Air binding has occurred	Perform a bypass blowdown, or close the trap inlet valve and allow the trap to cool
	Air binding due to disc holder ring or air vent ring wear	Replace with new disc holder ring or air vent ring
	Steam-locking has occurred	Perform a bypass blowdown, or close the trap inlet valve and allow the trap to cool
	Trap operating pressure exceeds the maximum specified pressure or there is insufficient pressure differential between the trap inlet and outlet	Compare specifications and actual operating conditions
	Trap capacity is insufficient	Replace with trap of suitable capacity
Steam is discharged or leaks from the outlet (blowing) (steam leakage)	Rust or scale on the disc or on the module valve seat	Clean parts
	Disc and the module valve seat damage or wear	Replace with new disc or module valve seat
	Improper installation	Correct the installation
	Trap vibration	Lengthen inlet piping and fasten securely
	Trap operating pressure is less than the minimum specified pressure or the back pressure exceeds the allowable back pressure	Compare specifications and actual operating conditions
Steam is leaking from a place other than the outlet	Gasket deterioration or damage	Replace with new gasket(s)
	Improper tightening torques were used	Tighten to the proper torque

NOTE: When replacing parts with new, use the parts list for reference, and replace with parts from the maintenance kit or repair kit. Please note that replacement parts are only available as part of a replacement parts kit.

## Product Warranty

1. Warranty Period  
One year following product delivery.
2. Warranty Coverage  
TLV CO., LTD. warrants this product to the original purchaser to be free from defective materials and workmanship. Under this warranty, the product will be repaired or replaced at our option, without charge for parts or labor.
3. This product warranty will not apply to cosmetic defects, nor to any product whose exterior has been damaged or defaced; nor does it apply in the following cases:
  - 1) Malfunctions due to improper installation, use, handling, etc., by other than TLV CO., LTD. authorized service representatives.
  - 2) Malfunctions due to dirt, scale, rust, etc.
  - 3) Malfunctions due to improper disassembly and reassembly, or inadequate inspection and maintenance by other than TLV CO., LTD. authorized service representatives.
  - 4) Malfunctions due to disasters or forces of nature.
  - 5) Accidents or malfunctions due to any other cause beyond the control of TLV CO., LTD.
4. Under no circumstances will TLV CO., LTD. be liable for consequential economic loss damage or consequential damage to property.

\* \* \* \* \*

For Service or Technical Assistance:


Contact your **TLV** representative or your regional **TLV** office.

### Manufacturer

**TLV** CO., LTD.  
881 Nagasuna, Noguchi  
Kakogawa, Hyogo 675-8511 JAPAN  
Tel: 81-(0)79 - 427 - 1800

## Option: With BO2 Blowdown Valve

### Configuration



### BO2 Blowdown Valve Instructions

The BO2 Blowdown Valve, installed in the screen area, uses the trap's internal pressure to blow any condensate, other fluids, dirt or scale from inside the trap out to atmosphere.

#### BO2 Blowdown Valve Operation



Install properly and **DO NOT** use this product outside the recommended operating pressure, temperature and other specification ranges. Improper use may result in such hazards as damage to the product or malfunctions which may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.



Take measures to prevent people from coming into direct contact with product outlets. Failure to do so may result in burns or other injury from the discharge of fluids.



Do not use excessive force when connecting threaded pipes to the product. Over-tightening may cause breakage leading to fluid discharge, which may cause burns or other injury.

1. The blow valve is in the closed position when the BO2 is shipped from the factory. Before attempting to operate the BO2, reconfirm that the blow valve is still in the closed position. Locate the blow outlet and, during operation, stand to the side and well clear of it, as the jet of condensate or other fluids could cause burns.
2. Remain in the area the entire time the blow valve is in the open position. Before opening the blow valve, grip the blow valve seat with a wrench and hold firmly in place so that it will not rotate when the blow valve is loosened. Grip the blow valve with another wrench and slowly loosen. Condensate and other fluids will discharge from the blow outlet in a jet stream. Be careful not to loosen the blow valve so far that it becomes removed from the blow valve seat. (If the grooved pin becomes damaged, large quantities of steam will be discharged in a jet stream.)
3. Close the blow valve until the flow of fluid completely stops. If the flow of fluid does not stop, re-open the valve (as in step 2) to blow out any scale or dirt that may be caught in the valve. Re-tighten the valve until the flow of fluid stops completely.

(Avoid the use of excessive tightening torques, as threaded parts may become damaged.)

Tightening Torques and Distance Across Flats			
Part	Torque		Distance Across Flats
Blow Valve Seat	40 N·m	29 (lbf·ft)	19 mm ( $\frac{3}{4}$ in)
Blow Valve	30 N·m	22 (lbf·ft)	17 mm ( $\frac{21}{32}$ in)

1 N·m  $\approx$  10 kg·cm